

Seicane S127682 2006-2012 Mercedes Benz Sprinter aftermarket car radio upgrade installation replacement instruction

Seicane S127682 2006-2012 Mercedes Benz Sprinter radio after installation



Please note:

This unit can be suitable for the following cars which are also with the same installation steps as follows.

2004-2012 Mercedes Benz A Class W169 A150, A160, A170, A180, A200

2004-2012 Mercedes Benz B Class W245 B150, B160, B170, B180, B200, B55

2006-2012 Mercedes Benz Viano

2006-2012 Mercedes Benz Vito

2006-2012 Mercedes Benz Sprinter

211 CDI (OM 646) 309 CDI (OM 646)

311 CDI (OM 646) 509 CDI (OM 646)

411 CDI (OM 646) 213 CDI (OM 646)

511 CDI (OM 646) 313 CDI (OM 646)

215 CDI (OM 646) 315 CDI (OM 646)

415 CDI (OM 646) 515 CDI (OM 646)

216 CDI (OM 646) 316 CDI (OM 646)

516 CDI (OM 646) 218 CDI (OM 642)

224 (M 272) 318 CDI (OM 642)

324 (M 272) 418 CDI (OM 642)

424 (M 272) 518 CDI (OM 642)

524 (M 272) 319 CDI (OM 642)

519 CDI (OM 642) 209 CDI (OM 646)

Here are some precautions for this installation:

1. Before you start up any work, park your car well and unplug the negative power cable to avoid any danger.
2. Please make sure that all fastened wires are isolated with electrical tape.
3. Please make sure the ignition is off to avoid short circuit.
4. For your convenience, here's the recommended tools for removal and installation from Seicane, please check for more details: <http://www.seicane.com/car-dvd-dismantling-device-srd-400>

2006-2012 Mercedes Benz Sprinter radio installation guide

1. Detach the outer frame of the original car radio.



2. Use a screw driver to remove the screws marked with red circles.



3. Remove the screw on the lower right.



4. Remove the screw on the lower left.



5. Remove the screw on the upper left.



6. Remove the screw on the upper right.



7. Use a screw driver to remove the screws marked with red circles.



8. Remove the original car radio.



9. Check all the accessories for the new Seicane car radio.



10. Connect the harnesses to the back of the new Seicane car radio.



11. Insert the plug of the car into the socket of unit.



12. Remarks

- a. Plug in the radio antenna.
- b. Plug in the GPS antenna.



13. Install the new Seicane radio into the dashboard.



14. Fasten the new Seicane radio with 4 screws and install the frame back.



15. Turn on the new Seicane radio to have a comprehensive check. If everything works well, all the installation is done. If not, please check if all the cables are connected correctly.

Attention:

We suggest you arrange a professional to install it. If you have any questions about installation, please send us photos about your original car's plugs, we can make a wiring diagram for your car.